

Healthy Air Go

HA30

Safety & Use Guide



Read this guide before installing or using the unit. Keep it for future reference.

For the full HA30 manual, detailed diagrams and support, scan the QR code on the back page.

Intended Use & Safety

Use the HA30 only as a portable air purifier inside a vehicle passenger compartment. Connect only to a suitable 12 V DC vehicle power socket using the supplied power cable.

Do not operate, adjust, install, remove or reposition the unit while driving. Park safely first.

Do not open, dismantle, modify or attempt to repair the unit, cable or plug. Contact your supplier or Healthy Air Technology Ltd for support.

- Use only the supplied 12 V power cable and mounting strap.
- Rated input: 12 V DC. Rated power: 4.3 W.
- Keep away from liquids, moisture, heat, ignition sources and flammable materials.
- Do not block the air inlet or outlet.
- Do not place on the dashboard or in an airbag deployment area.
- This product is not a toy. Keep away from children.

Safe Operation

Stop using the unit if:

The unit, cable, plug or vehicle socket is damaged, wet, overheating, smoking, smelling unusual, making abnormal noise, dropped, or if the cover or filter cannot be fitted correctly.

Before leaving the vehicle

Some vehicle sockets remain powered after the engine is switched off, so the unit may continue operating.

Switch the unit off before leaving the vehicle unattended.

The automatic 2-hour shut-off feature helps reduce battery drain, but it should not replace safe unattended-use practice.

Supplied Items & Fitting

In the box



12 V power cable



Mounting strap

Fit the unit securely

1. Park safely before fitting or moving the unit.
2. Pass the strap through the two slots in the unit.
3. Attach to a suitable headrest or armrest.
4. Keep the unit and cable clear of controls, pedals, seatbelts, visibility, passengers and safe exit.
5. Check the unit is secure before driving. Do not use tape or rope.

Power & Operation



Short press changes fan speed. Hold 2-3 seconds for standby.

1. Connect the supplied cable to the unit.
2. Connect the plug to the vehicle 12 V power socket.
3. Short press the button to change fan speed.
4. Hold the button for 2-3 seconds to enter standby.

Fan speed and air quality

- One tone = low speed; two tones = medium speed; three tones = high speed.
- The blue, pink and red indicator lights show the detected air quality.
- In automatic mode, the unit adjusts fan speed according to the detected air quality.

Filter, Reset & Cleaning



RESET

Press with a pin
for 2-3 seconds.

1. Disconnect power before replacing the filter.
2. Remove the cover and pull the ribbon to remove the used filter.
3. Insert the new filter using the guide groove. It fits one way only; do not force it.
4. Press RESET with a pin for 2-3 seconds. Release after the double tone and when the indicator turns on.
5. Refit the cover. The unit starts in low-speed mode when reset is complete.

Cleaning

- Disconnect before cleaning.
- Wipe with a dry or slightly damp cloth.
- Do not use alcohol, petrol, diesel, corrosive cleaners, solvents, sprays or excessive water.
- Do not wash or reuse the filter.
- Use only replacement filters supplied or approved by Healthy Air Technology Ltd.

Troubleshooting & Disposal

Issue	What to check
Will not start	Cable, 12 V socket, cover and power button.
Runs after engine off	The socket may remain live. Switch off before leaving.
Indicator flashes	Replace the filter, then reset after replacement.
Odour remains	Continue use and ventilate safely where possible.

Electrical waste

The crossed-out wheeled bin symbol means this electrical product must not be disposed of with unsorted household waste.

- Take the unit and cable to an electrical recycling point or use retailer/HATL take-back where available.
- Used filters may go in normal household waste unless local rules require otherwise.

Support, Warranty & Manual

This product is covered by a 1-year warranty from the date of purchase when used according to the manual and for its intended purpose.

This warranty does not affect your statutory rights.

Responsible business:

Healthy Air Technology Ltd

Oxford University Begbroke Science Park, Begbroke, Oxford, OX5 1PF, United Kingdom

E-mail: admin@healthyairtech.co.uk

Website: www.healthyairtech.com



For the full HA30 online manual and support information, scan the QR code or visit: <https://healthyairtech.com/product-safety-user-manuals/>